

SG2100 EASY INSTALLATION INSTRUCTION

For South Hemisphere, please change South to North and exchange East and West in the following instruction.

STEP 1.

Make sure the pole/stand is exactly vertical to ground. Use a plumb and a level to do the vertical and level correction. Good pole/stand alignment is the first and the most essential step for the installation.



Level




Plumb

STEP 2.

Mount the motor onto the pole/stand. Align the centre of the motor, bracket and the pole/stand to the True South. To get the True South, use a compass to determine the Magnetic South and deduct the Magnetic Declination.

Find the Magnetic Declination of your location via:

http://www.geolab.nrcan.gc.ca/geomag/magdec_e.shtml



STEP 4.

Drive the motor via motor's manual button or the receiver to aim a satellite with stronger signal, which is better not far from the True South.

GotoX function can help calculate the degree the motor should rotate to.

STEP 5.

In the angle mentioned above, there should be **signal**, and fine-tune the elevation / declination / azimuth angle / True South (Rotate the whole motor+dish) to get the best reception **signal**.

Then, scan the satellite and store the channels.

STEP 6.

Repeat step 4 & 5 for other satellites.

STEP 7.

After completing the installation, mark the current position just in case.



TROUBLESHOOTING & FAQ

Symptoms or Questions	Check points or Answers
<p>What is Magnetic South and True South?</p>	<p>The direction in which the compass points is referred to as Magnetic South instead of True South. In fact, there is an angle difference called Magnetic Declination between these two. Find the Magnetic Declination of your location via: http://www.geolab.nrcan.gc.ca/geomag/magdec_e.shtml</p>
<p>After fine tune, there is still weak signal or no signal at all in the aimed satellite position.</p>	<ol style="list-style-type: none"> 1. Make sure the coaxial cable is well connected. 2. Make sure all the satellite equipments work properly. Also make sure all the receiver's setting (LNB, Frequency, Symbol rate....) is correct. 3. Make sure the pole/stand is straight and vertical to the ground.
<p>Only one or two satellites' signal are receivable.</p>	<p>It might be the reception arc does not correspond to the satellites arc. Make sure the pole/stand is straight and vertical to the ground, and fine-turn the elevation / declination / azimuth angle patiently.</p>
<p>What is GotoX function?</p>	<p>It is a standard DiSEqC 1.2 command that drives motor to needed angle. Some receivers support this function and even can calculate the right angle to the aimed satellite according to your longitude and latitude.</p> <p style="text-align: right;">http://www.dmsiusa.com</p>